

Low Shrinkage Mix Design Optimization Guidelines for Eclipse® Floor 200

TB1001

Introduction

Eclipse® Floor 200 Shrinkage Reducing Admixture is a liquid concrete admixture specifically formulated for reducing the drying shrinkage properties of non air-entrained concrete. This technical bulletin details mix design optimization recommendations which will enhance the potential of eliminating or dramatically reducing drying shrinkage cracking in slab-on-grade construction. The inclusion of Eclipse® Floor 200 at a minimum dosage rate of 3.7 L/m³ (0.75 gal/yd³) should be included in these design modifications. If available, testing at 7.4 L/m³ (1.5 gal/yd³) may provide greater shrinkage reduction favorable to greater joint spacing. Testing a three point curve using 3.7–4.9–7.4 L/m³ (0.75–1.0–1.5 gal/yd³), Eclipse® Floor 200 will provide optimal test data to determine drying shrinkage performance vs. Eclipse® Floor 200 dosage rate.

Maximum 0.50 Water/Total Cementitious Ratio

- Admixtures, not water, should be used to achieve required workability, since water is the primary detriment for drying shrinkage.
- 18 kg (40 lbs) reduction in water content will reduce the drying shrinkage by approximately 15%.
- The lower the water/cement ratio, the lower the drying shrinkage is.

Admixture Selection

- Recommended use of ADVA® type superplasticizers to optimize mix design shrinkage characteristics and to achieve low water/cement ratios. Mid-range water reducers may not be as favorable to shrinkage performance as ADVA® type superplasticizers. ADVA® type superplasticizers will allow for water reduction to meet water/cement ratio requirements while providing workability, and will help to optimize drying shrinkage properties when used in conjunction with Eclipse® Floor 200.
- Avoid utilizing chloride containing admixtures.
- Avoid superplasticizers which can promote retardation at higher addition rate.

Coarse Aggregate-Major Impact on Drying Shrinkage Properties

- Increase coarse aggregate content to minimum 1,040 kg/m³ (1,750 lbs/yd³). Use larger size aggregates when locally available. Mixes utilizing 19 mm (0.75 in.) aggregate can shrink up to 30% more than mixes utilizing 25 mm (1 in.) aggregate.
- Utilize quality aggregates that have low absorption and compressibility (modulus of elasticity) properties. Sandstone and slate aggregates may have poor shrinkage properties while limestone, dolomite, granite and feldspar often have low (good) shrinkage properties.

Cementitious Constituents

- Quantify cement brand impact on drying shrinkage by testing.
- Type II cements usually shrink less than Type I and much less than Type III cements.
- Fly ash and slag are fully compatible with mixes containing Eclipse® Floor 200.

Minimum 28 MPa (4000 psi) 28 Day Compressive Strength

- Inclusion of Eclipse® Floor 200 may result in 28 day strength reduction on the order of 10% relative to an identical mix not containing Eclipse® Floor 200.
- Strength should be designed by the engineer for anticipated loads.

Use of Eclipse with Type A Water Reducers

- Inclusion of Eclipse® Floor 200 may result in set retardation, typically in the 45 minute range when utilized as a stand-alone admixture. This can be amplified by the use of some Type A water reducer and some pozzolans.
- Trial mixes are recommended to determine time of set characteristics of the Eclipse® mix.

Mix Design Review and Test Matrix – Optional

- GCP Sales personnel and the Regional Technical Service Manager will review test matrix and proposed mix designs to share best practices.
- Furnish current data available for the control mix. Data should include compressive strength tests, shrinkage data, aggregate gradations and a history of mix design performance.
- Review period will take 10–15 business days after the Regional Technical Service Manager receives all information.

Shrinkage Testing

Mix designs must be evaluated for drying shrinkage properties via ASTM C157, *“Standard Test Method for Length Change of Hardened Hydraulic-Cement Mortar and Concrete”* (See Eclipse® Shrinkage Testing technical bulletin).

- Assure testing lab has appropriate equipment, personnel and experience.
- Recommend 7 day wet cure (versus 28 days).
- An initial reading (one day reading) should be taken per ASTM C157 at 24 hr ± 1/2 hr.
- Air dry readings should be taken at minimum 3, 7, 14, 21 and 28 days. A reading at 56 days will lead to more accurate understanding of mix design drying shrinkage properties.
- Eclipse® Floor 200 mixes should be compared against the same mix without Eclipse® Floor 200 (reference mix).

Trial Placement

A pre-job test pour is recommended using a minimum three cubic yards. The trial pour should be used to determine setting characteristics, workability and general suitability for desired field performance.

gcpat.my | Malaysia customer service: 603 9074 6133

Eclipse and ADVA are registered trademarks of GCP Applied Technologies.

We hope the information here will be helpful. It is based on data and knowledge considered to be true and accurate and is offered for consideration, investigation and verification by the user, but we do not warrant the results to be obtained. Please read all statements, recommendations and suggestions in conjunction with our conditions of sale, which apply to all goods supplied by us. No statement, recommendation, or suggestion is intended for any use that would infringe any patent, copyright, or other third party right.

Strux is a trademark, which may be registered in the United States and/or other countries, of GCP Applied Technologies Inc. This trademark list has been compiled using available published information as of the publication date and may not accurately reflect current trademark ownership or status.

© Copyright 2017 GCP Applied Technologies Inc. All rights reserved.

GCP Applied Technologies Inc., 62 Whittemore Avenue, Cambridge, MA 02140 USA.

In Canada, 294 Clements Road, West, Ajax, Ontario, Canada L1S 3C6.

This document is only current as of the last updated date stated below and is valid only for use in Malaysia. It is important that you always refer to the currently available information at the URL below to provide the most current product information at the time of use. Additional literature such as Contractor Manuals, Technical Bulletins, Detail Drawings and detailing recommendations and other relevant documents are also available on www.gcpat.my. Information found on other websites must not be relied upon, as they may not be up-to-date or applicable to the conditions in your location and we do not accept any responsibility for their content. If there are any conflicts or if you need more information, please contact GCP Customer Service.

Last Updated: 2018-08-27

gcpat.my/solutions/products/eclipse-concrete-shrinkage-reducing-admixtures/low-shrinkage-mix-design